



HE-GMBK10

2015-2018 Chevy Colorado/GMC Canyon Hidden Mount for a 30" Light Bar

Tools Needed: 7mm/10mm/15mm Socket and wrench, T15 Torx, Reciprocating Saw or another plastic cutting tool

NOTE: This will only fit a low profile light bar

Instructions:

1. Remove the factory bumper cover in accordance with the owner's manual from the manufacture on proper bumper removal.
2. Once the bumper is removed, set aside in a safe location.
3. Remove the four 15mm bolts that secure the crash bar to the frame.
4. Remove crash bar and set aside.
5. Cut and remove the 8 vertical bars in the lower grille this will ensure the maximum space needed to properly fit the light bar.
6. Place the light bar brackets inside of the air ducts and align the bracket's mounting holes with the crash bar's mounting holes.

7. Reinstall crash bar with the four 15mm factory bolts.
8. Attach the 30" low profile light bar to the installed light bar brackets using the light bar's supplied hardware.
9. Run the light bar's power wire to the proper location for your application, and avoid pinch points or areas that might sever the power wire.
10. Test the light bar and its functions to ensure all connections were properly made.
11. Replace bumper cover back into the vehicle in accordance with manufacture's specs.
12. Congratulation you are done.



1-800-221-0932 **www.HeiseLED.com**
460 Walker Street, Holly Hill, FL 32117