



HeiseLED® Technical Bulletin Universal 8 Gang Switch Panel System

This Bulletin offers assistance if installing the panel in a vehicle that does not have a illumination circuit or that does not rest at 0volts (i.e. UTV, side-by-side), or you want the backlight to come on with ignition.

Add a SPDT relay such as a metra E-123 SPDT relay to activate the blue led back light of the HE-SWP8 panel.

1. Connect the white 22 gauge wire to terminal 30 of the SPDT relay.
2. Connect terminal 85 and 87 of the SPDT relay to the same location in the vehicle as the 22 gauge yellow wire.
3. Connect terminal 86 of the SPDT relay to ground point in the vehicle.
4. Test functionality, if you are unsuccessful contact tech support for further assistance.

