



70-8114 Toyota/Lexus/Scion ASWC-1 harness

Installation:

1. Connect the **Red** wire to 12-volt accessory power.
2. Connect the **Black** wire to chassis ground (by itself).
3. Connect the 3.5mm jack to the steering wheel control input, in the aftermarket radio.
4. Connect the **White** RCA jack to the left audio AUX IN of the aftermarket radio (if equipped).
5. Connect the **Red** RCA to the right audio AUX IN of the aftermarket radio (if equipped).

Note:

- Audio devices connected through the 3.5mm jack will be controlled from the audio device, not the aftermarket radio.
- Please refer to the ASWC-1 programming instructions for programming of the ASWC-1.

APPLICATIONS

LEXUS		TOYOTA			
ES-Series	2002-2006	4-Runner*	2012-2013	Matrix	2009-2012
GX-Series	2003-2009	4-Runner	2003-2011	Prius	2004-2011
RX-Series	2004-2009	Avalon	2005-2012	Rav-4	2005-2011
		Camry	2005-2011	Sequoia*	2013-up
		Corolla*	2011-2013	Sequoia	2003-2012
SCION		Corolla	2009-2010	Sienna	2003-2014
iQ	2012-up	FJ Cruiser*	2013-up	Solara (Camry)	2004-2008
tC	2005-2013	FJ Cruiser	2007-2012	Tacoma*	2012
xA	2004-2006	Highlander*	2013	Tacoma	2005-2011
xB	2004-up	Highlander	2004-2012	Tundra	2003-2013
xD	2008-up	Matrix*	2013	Venza	2009-2012

* These vehicles use either a 20-Pin or 28-pin connector for the steering wheel control harness. If your vehicle uses a 28-pin connector, please use the AX-TOY28SWC instead.

Caution: Metra recommends disconnecting the negative battery terminal before beginning any installation. All accessories, switches, and especially air bag indicator lights must be plugged in before reconnecting the battery or cycling the ignition.

Note: Refer also to the instructions included with the aftermarket radio.

Connections to be made

When installing an aftermarket radio, the 70-8114 will allow the user to retain their factory installed steering wheel controls without having to splice into the factory wiring (ASWC-1 required and sold separately). In addition, we include RCA's to allow the user to retain their factory installed 3.5mm AUX IN jack (aftermarket radio must have a audio AUX IN).

Continued on back



KNOWLEDGE IS POWER
Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installermetra.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



Metra recommends MECP certified technicians



1-800-221-0932



metraonline.com



1-800-221-0932



metraonline.com



70-8114 Arnés ASWC-1 Toyota/Lexus/Scion

Instalación:

1. Conecte el cable **rojo** de alimentación auxiliar de 12-voltios.
2. Conecte el cable **negro** a tierra del chasis (por sí mismo).
3. Conecte el jack de 3.5 mm para la entrada de control del volante, en la radio no original.
4. Conecte el conector RCA **blanco** a la izquierda de audio AUX IN de la radio no original (si está instalado).
5. Conecte el RCA **rojo** a la derecha de audio AUX IN de la radio no original (si está instalado).

Nota:

- *Los dispositivos de audio conectados a través del conector de 3,5 mm se controlan desde el dispositivo de audio, sin la radio no original.*
- *Por favor, consulte las instrucciones de programación ASWC-1 para la programación de la ASWC-1.*



EL CONOCIMIENTO ES PODER
 Mejore sus habilidades de instalación y fabricación inscribiéndose en la escuela de dispositivos electrónicos móviles más reconocida y respetada de nuestra industria. Regístrese en www.installerinstitute.com o llame al 800-354-6782 para obtener más información y avance hacia un futuro mejor.



Metra recomienda técnicos con certificación del Programa de Certificación en Electrónica Móvil (Mobile Electronics Certification Program, MECP).



1-800-221-0932



metraonline.com

APLICACIONES

LEXUS		TOYOTA			
ES-Series	2002-2006	4-Runner*	2012-2013	Matrix	2009-2012
GX-Series	2003-2009	4-Runner	2003-2011	Prius	2004-2011
RX-Series	2004-2009	Avalon	2005-2012	Rav-4	2005-2011
		Camry	2005-2011	Sequoia*	2013-up
		Corolla*	2011-2013	Sequoia	2003-2012
		Corolla	2009-2010	Sienna	2003-2014
		FJ Cruiser*	2013-up	Solara (Camry)	2004-2008
iQ	2012-up	FJ Cruiser	2007-2012	Tacoma*	2012
tC	2005-2013	Highlander*	2013	Tacoma	2005-2011
xA	2004-2006	Highlander	2004-2012	Tundra	2003-2013
xB	2004-up	Matrix*	2013	Venza	2009-2012
xD	2008-up				

** Estos vehículos utilizan ya sea un 20 pines o un conector de 28 pines para el arnés de control del volante. Si su vehículo utiliza un conector de 28 pines, por favor, utilice el AX-TOY28SWC lugar.*

Caution: Ubique el arnés del cableado de fábrica en el tablero. Metra recomienda usar el adaptador de acoplamiento adecuado de Metra o AXCESS. Vuelva a conectar el terminal negativo de la batería y pruebe la unidad para verificar que funcione correctamente.

Nota: Vuelva a montar el tablero en forma inversa al desmontaje.

Conexiones que se deben hacer

Al instalar un radio de posventa, el 70-8114 permitirá al usuario retener sus controles del volante instalados de fábrica sin tener que realizar un empalme al cableado de fábrica (requerido por el ASWC-1 y vendido por separado). Además, incluimos los conectores RCA para permitir que el usuario retenga su enchufe de 3.5 mm instalado de fábrica (el radio de posventa debe tener una entrada auxiliar).

Continúa en la página



1-800-221-0932



metraonline.com