

## BC-HDLFP

### Lower Fairing Speaker Pods – Twin Cooled models

1. Using a panel pry tool, remove the cover.




2. Using an 11MM socket with extension, remove the nut holding the front cover in place. Remove the front cover.



3. Remove the (2) 11MM bolts from the clamp, securing housing to the crash bar.



4. Using gentle pressure, push the housing to the rear of the motorcycle. Remove (3) three, 11mm bolts from the guard.



5. Locate vent level, using a T25 remove bolt and lever from assembly.



6. Remove slip in the outside, lower corner of the pod to the fairing. Transfer plastic clip to speaker pod.



7. Run speaker wire to pod, and reinstall in reverse order of removal.

8. Install speaker per the speaker manufactures instructions, using included grille or from speaker manufacturer. Installation is same on both sides of Motorcycle.

