




DAYTONA LIGHTS™

DL-RGBK2



- RF Key Fob
- A: Activate music function
 - B: Power
 - C: Activate color mode and Changes color
 - D: Patterns

After thoroughly cleaning mounting surface, remove the protective tape and stick the LED strip to the mounting surface.

Connections	
*Use cigarette adapter or loose wires	
Loose Wires:	Red - 12V+
	Black - Chassis Ground
	Blue - Brake Trigger
Brake Trigger:	Connect the blue wire to the 12V+ brake light wire. When the brake light is activated, the LEDs will switch to red. LEDs will return to previous state once the brake is released.

Single color Selection

4 Color Changing Modes