



HeiseLED® Technical Bulletin

Universal 8 Gang Switch Panel System

This Bulletin offers assistance if you are having trouble programming the latched or momentary switch operation.

To enable or disable the momentary function, follow this procedure.

1. Ignition must be off (No power to the Yellow wire).
2. Turn on the HE-SWP8 (Press the Heise® Red Atom button then let go) then proceed to the next step.
3. Press hold the Atom, count 2 seconds (**thousand 1, thousand 2**) continue holding proceed to the next step.
4. Press and hold accessory button until the LED flashes, then let go of buttons .
5. Test functionality, if you are unsuccessful power off and repeat steps 1-4.