

Subaru † Backup Camera Retention 2015-Up

† Base models with a 6.2-inch screen

* It is highly recommended to use the **AXCSD-6V** (sold separately) to provide the camera with the proper voltage

Visit axxessinterfaces.com for more detailed information about the product and up-to-date vehicle specific applications

HARNESSES

- AXBUCH-SB2 harness

APPLICATIONS

SUBARU*

Crosstrek	2016-2017	WRX	2016-Up
Forester	2017-2018	WRX (w/ NAV)	2015
Impreza	2015-2016	XV Crosstrek	2015

* All vehicles will require an **AXCSD-6V** 12V to 6V step down

TOOLS REQUIRED

- Crimping tool and connectors, or solder gun, solder, and heat shrink
- Tape • Wire cutter • Zip ties

CONNECTIONS

To retain the factory backup camera to an aftermarket radio, connect the:

- **Black** wire to chassis ground.
- **Black** wire from the **AXCSD-6V** to chassis ground.
- **Red** wire to the **Blue/Red** wire from the **AXCSD-6V**.
- **Blue/White** wire from the **AXCSD-6V** to accessory power.
- **Yellow** *male* RCA jack to the backup camera input from the aftermarket radio.
- Disregard the *female* **Yellow** RCA jack.