


JP-709RGBKT | PREMIUM HEADLIGHTS

INSTALLATION INSTRUCTIONS



BEFORE YOU START

Before you start, make sure you have everything that is needed for the installation. These models require additional parts.*

2018-Up Wrangler JL - Any trim 2020-Up Gladiator - Any trim

- JP-JLB7 headlight bracket
- JP-TSH1 (optional) DRL, parking light, and turn signal T-harnesses

*Please visit MetraOnline.com for the latest application details.

GENERAL SPECIFICATIONS

CHASING CONTROLLER

7" HEADLIGHTS

- 49 watts each
- Lumen: 3000lm (high beam), IP rating: IP67K

1900lm (low beam)

- Color Temperature: 6500K ٠
- Material: Die-cast aluminum ٠ alloy housing

- Lens: Polycarbonate
- Operating Voltage: 12V
- H4 to H13 connectors included
- DIY pattern and music sync function
 - App controlled
 - RF card remote included

Turn signal halo function

Addressable I FD controller

170+ color changing patterns



download app



WRANGLER JK HEADLIGHT REMOVAL

- 1. Open hood and remove the (6) push pin clips across the top of the grille using a plastic pry tool. (Figure A)
- 2. Gently lean grille forward to access panel clips at rear bottom of grille. Using a panel pry tool, release grille from clips. (Figure B)
- 3. Disconnect the left and right turning signal. (Figure C)
- Remove the (4) T-15 Torx[®] screws from each headlight retaining ring. New headlights will be secured in place with the factory hardware.(Figure D)
- 5. Unplug and remove the headlight.
- 6. Trim off keyway from the factory mounting plate. (Figure E)
- 7. Connect the included H4 adapter and Canbus decoder to the vehicle harness for each headlight.
- 8. Continue to installation on page 5.



Figure A



Figure C



Figure B



Figure D



Figure E

WRANGLER JL AND GLADIATOR HEADLIGHT REMOVAL

- Open hood and remove the (6) 1. push pin clips across the top of the grille using a plastic pry tool. (Figure A)
- Pressure clips will be the only 2. things holding the grille to the Jeep at this point. Pull from the bottom corner of the grille to release the clips and remove grille. (Figure B) Remove the (3) 10mm bolts from
- 3. the headlight assembly.
- Unplug and remove the headlight. Install JP-JLB7 headlight brackets 4.
- 5. (not included), and plug the H4 to OE adapter into the factory headlight harness (included with JP-JLB7).
- 6. Continue to installation on page 5.



Figure A




Figure **B**

INSTALLATION

- 1. Locate a suitable location to mount the Pro Chasing controller inside the engine bay.
- 2. Connect the black wire from the controller to chassis ground. There are several factory ground points along the fire wall and sides of the engine bay.
- 3. Connect the red wire from the controller to a switched +12VDC source. Adding a 10 amp in-line fuse is recommended. On 2018-Up Wrangler JL and 2020-Up Gladiator, using the JP-TSH1 (sold separately) will provide an easy light switch controlled power source, and connections for turn signal triggers.
- 4. Using a digital multi-meter, locate the +12VDC wire for the left and right turn signals located at the lights. Note the wire colors. Connect the green wire from the controller to the left (driver) turn signal wire, and connect the yellow to the right (passenger) turn signal wire.
- 5. Run the left channel 4 pin cable to the driver side headlight, making sure to avoid hot surfaces and pinch points. Secure the cables approximately every six inches.
- 6. Run the right channel 4 pin cable to the passenger side headlight, making sure to avoid hot surfaces and pinch points. Secure the cables approximately every six inches.
- 7. Connect the 4 pin cable to the new headlight and plug the H4 connector into the vehicle harness or previously installed adapter. Mount headlight into vehicle, then repeat on the other side.
- 8. Download app (QR code on back cover of instructions) for smart phone control, and refer to Pro Controller instructions for setup. Pro Controller can also be controlled from RF remote (included).
- 9. In the app set the chase pixel count to 77.
- 10. Test the low beam, high beam, turn signals, and chasing functions.
- 11. Preform any needed adjustments on the new headlights. The adjustment is to properly aim the lights to generate the correct beam pattern. Details on the procedure can be found in the vehicle service manual. There is also support videos on <u>MetraOnline.com</u>.
- 12. Reinstall grille.

DIAGRAM



Having difficulties? We're here to help.



Contact our Tech Support line at: 386-257-1187

Or via email at: \bowtie techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM Saturday: 10:00 AM - 7:00 PM Sunday: 10:00 AM - 4:00 PM



KNOWLEDGE IS POWER ®

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow





Jeep[®] Accessories

IPOTANT: Document date of purchase, and place of purchase.
ate:
lace of Purchase:
istall Notes:



Jeep® Accessories



Thank you for purchasing your lighting from Metra Electronics! We're excited to see your installs, scan the QR to share on our Instagram. If you have any questions, comments, feedback on the product, please contact our tech support email via <u>techsupport@metra-autosound.com</u>.

Don't forget to Visit <u>HEISELED.COM</u> to view the available installation parts and Jeep accessories.





Metra Electronics Corp. ®

Metraonline.com

©COPYRIGHT 2020 METRA ELECTRONICS CORPORATION

REV. 05/15/2023 INSTJP-709RGBKT