



## Cadillac Chime Interface 1997-2006

### INTERFACE FEATURES

- Used in amplified systems
- Provides accessory power (12-volt 10-amp)
- Provides NAV outputs (parking brake, reverse, and speed sense)
- Retains R.A.P. (Retained Accessory Power)
- Prewired AXSWC harness included (AXSWC sold separately)
- Retains chimes
- Retains OnStar<sup>®</sup>/OE Bluetooth
- Adjustable volume for chimes and OnStar<sup>®</sup>
- High level speaker input
- Retains balance and fade
- Micro B USB updatable

### INTERFACE COMPONENTS

- AXGM-16 interface
- LD-GMOS-26 harness
- LD-GMOS-210 harness
- LD-2NAVAMP harness

### APPLICATIONS

<b>Cadillac</b>		
Catera .....	1997-2001	Eldorado .....
CTS .....	2003-2006	Seville .....
Deville .....	1998-2005	SRX (with RPO codes UZR U2S).....
		1998-2002
		1998-2004
		2004-2006

### TABLE OF CONTENTS

Connections	
LD-GMOS-26 harness .....	2
LD-GMOS-210 harness .....	3
Installation .....	4
Programming.....	4


### TOOLS & INSTALLATION ACCESSORIES REQUIRED

- Cutting tool • Tape • Crimping tool
- Connectors (i.e. butt-connectors, bell caps, etc.)


Visit [AxxessInterfaces.com](http://AxxessInterfaces.com) for more detailed information about the product and up-to-date vehicle specific applications

**ATTENTION:** With the key out of the ignition, disconnect the negative battery terminal before installing this product. Ensure that all installation connections, especially the air bag indicator lights, are plugged in before reconnecting the battery or cycling the ignition to test this product. **NOTE:** Refer also to the instructions included with the aftermarket accessory before installing this device.

## CONNECTIONS: LD-GMOS-26 & LD-2NAVAMP



## CONNECTIONS: LD-GMOS-210 & LD-2NAVAMP



### INSTALLATION

#### With the key in the off position:

- Connect either the **LD-GMOS-26 harness** or **LD-GMOS-210 harness** and **LD-2NAVAMP harness** into the interface, and then to the wiring harness in the vehicle.

### PROGRAMMING

**Attention!** If the interface loses power for any reason, the following steps will need to be performed again. Also, if installing an AXSWC connect it after you initialize and test the interface/radio, with the key in the off position.

- Turn the key (or push-to-start button) to the ignition position and wait until the radio comes on.

**Note:** If the radio does not come on within 60 seconds, turn the key to the off position, disconnect the interface, check all connections, reconnect the interface, and then try again.

- Turn the key to the off position, and then to the accessory position. Test all functions of the installation for proper operation, before reassembling the dash.

Having difficulties? We're here to help.



Contact our Tech Support line at:

**386-257-1187**



Or via email at:

[techsupport@metra-autosound.com](mailto:techsupport@metra-autosound.com)

#### Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 5:00 PM

Sunday: 10:00 AM - 4:00 PM



#### **KNOWLEDGE IS POWER**

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto [www.installerinstitute.edu](http://www.installerinstitute.edu) or call 386-672-5771 for more information and take steps toward a better tomorrow.



**Metra recommends MECP  
certified technicians**